

Lab 9: Serial Peripheral Interface ECE 3720



Preview

The PIC32's SPI module will be used to send data serially to the AD2, which will display its value on a logic analyzer. Each time a button is pressed, the MC will send a new value to the AD2.


Topic	Slide
Serial Peripheral Interface	<u>3</u>
SPI Module Diagram	<u>4</u>
Using SPI	<u>5</u>
SN74HC595 (shift register)	<u>6</u>
Lab Goals	<u>7</u>
Notes	<u>8</u>



Serial Peripheral Interface (SPI)

- SPI is a communication protocol often used for short-distance communication in embedded systems.
 - Serial communication sends data one bit at a time over a single channel.
- Master-slave architecture
 - Each can send data to the other.
 - Master provides the clock and slave select signals (slave select tells that particular device to listen).
 - PIC32 can operate as master or slave. We'll use it in master mode.

The terms **MOSI** (Master Out, Slave In) and **MISO** (Master In, Slave Out) are often used to refer to the two data channels.



PIC32 FRM - Section 23. SPI, pg. 4

The SPIx serial interface consists of four pins:

- SDIx: Serial Data Input
- SDOx: Serial Data Output
- SCKx: Shift Clock Input or Output
- SSx: Active-Low Slave Select or Frame Synchronization I/O Pulse




SPI Module Diagram

Write transmit data and read received data from SPIxBUF

- Data propagates automatically to SPIxTXB (transmit) or from SPIxRXB (receive)
- You will only write to SPIxBUF

Output pins

- SDOx and SSx must be mapped with PPS
- SCKx is hard mapped to a specific pin



Baud Rate Generator

- Baud rate refers to rate of data transfer (bits/s)
- Here, the BRG divides the clock to achieve desired rate




Using SPI

- The document **Section 23 Serial Peripheral Interface** is available on Canvas in the Lab 9 module.
 - Contains all the information about the PIC32's SPI capabilities
- Follow the steps in **Section 23.3.3.1 Master Mode Operation.**
 - This covers the majority of what you need to do in your code.
 - Study pages 18-20 for a better understanding.
 - See the notes at the end of these slides for details on what values you will set.
- Registers of interest
 - SPIxBUF //write or read data
 - SPIxCON //configure SPI module (pg. 8)
 - SPIxSTAT //SPI module status (pg. 13)
 - SPIBRG //divisor for baud rate generator



Lab Goals

- Use the PIC32 in SPI master mode to send the values from the given array to the AD2.
- Connect the AD2 inputs as shown in the diagram.
- Set up an external interrupt. Each time it's triggered, the next value in the array should be written to SPIxBUF and appear on the LEDs.




Array of values to display:

char spiChars[18] = {0, 1, 2, 4, 8, 16, 32, 64, 128, 255, 254, 253, 251, 247, 239, 223, 191, 127};



Logic Analyzer

- The logic analyzer allows you to see output of a specific protocol.
- We will be using the SPI protocol.
- Select what DIO pins you want to use, and how you would like to see the data.
- Set the base to >100 ms/div







Notes

- The SPI module can transmit 8-, 16-, or 32-bit bit data. What data width will be needed for this lab, and how is that mode selected? (see section 23.3.1)
- The following is a checklist of values to set (located in SPI1CON, unless otherwise specified)

```
FRMPOL = 1
                            // Make SSx active-high to use with SRCLR (so shift register gets cleared when data is NOT transmitted)
IEC1bits.SPIRX = 0
IEC1bits.SPITX = 0
                            // Disable SPI interrupts
ON = 0
                            // Disable SPI module during setup
SPI1BUF
                            // Don't want enhanced buffer mode
ENHBUF = 0
CKP, CKE
                            // See figure 23-9 in Section 23 document (pg. 20)
                            // Should result in baud rate slow enough to observe transmission with oscilloscope
SPIBRG = 2000
SPIROV
                            // In SPI1STAT
MSTEN, MSSEN
ON = 1
                            // Enable SPI module after setup is complete
```